

SLC/MicroLogix 1500 to CompactLogix Migration Guide





Important User Information

Solid-state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (publication <u>SGI-1.1</u> available from your local Rockwell Automation[®] sales office or online at <u>http://www.rockwellautomation.com/literature/</u>) describes some important differences between solid-state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid-state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



Allen-Bradley, Rockwell Software, Rockwell Automation, CompactLogix, ControlLogix, MicroLogix, Studio 5000, RSLogix, POINT I/O, FLEX, and TechConnect are trademarks of Rockwell Automation, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Table of Contents	Important User Information	. 2
Preface	About This Publication Studio 5000 Environment Additional Resources	. 5
	Chapter 1	
Overview	Why Convert. What Is Needed. SLC EtherNet/IP Adapter. 1747-AENTR Connections. 1747-AENTR and Rack Optimization. Exclusive Owner, Input Only, Listen Only, and None Connection Types.	. 7 . 7 . 8 . 9 . 9
	Add I/O Modules Online	10
	Using the 1747-AENTR Module in a Redundant Logix System	10
	SLC to Logix Memory Comparison	11
	Local Rack SLC 500 I/O Modules	11
	Remote Rack SLC 500 I/O Modules	12
	Overall Performance Expectations	12
	Logix Controller Boot Time	13
	Synchronous Versus Asynchronous I/O Scans	13
	Keeping I/O	14 14
	Chapter 2	
Migration Considerations	Document Current System Layout	15
	PLC-5/SLC Interactive Migration Planner	15
	Define Future Requirements	17
	Device-level King Topologies	1/17
	Use of Advanced Modules	18
	Communication With an SLC Controller Over DH485, DH+,	10
	Ethernet, or Serial Networks	18
	1747-AENTR Backplane Power Considerations	19
	Using Integrated Architecture Builder to Plan Hardware Migration	20
	Replace Only the Local SLC Controller	20
	Replace the Local SLC System with CompactLogix System Adding a Chassis Network Connection Options for the Remote (SLC System) I/O	26 33
	Chassis Create Project Bill of Material	36 41

	Chapter 3	
Conversion	Introduction . Download the standalone RSLogix Project Migrator. What to Expect from the RSLogix Project Migrator . Application Code Conversion. Translate an RSLogix 500 Program to a Logix Designer Program Resolve the Differences in the New Logix Program SLC Controllers Data Tables and Logix Controller Tags Resolve Program Code Issues Locating PCE Instructions Recognizing the Instructions Resolving PCE Instructions Resolving PCE Instructions Common PCE Issues	43 43 45 50 57 57 57 58 59 59
	Map PLC/SLC Messages	61
	MOV Example	62
	CPS Example	63
	Alias Example	65
	Replace SLC Processor and Adapters	66
	Set the Network Address Switches	66
	Determine Power Requirements	67
	Install the Adapter Module in the Chassis	67
	Connect Your Adapter to the Ethernet/IP Network through RJ45	; ,
		69
	Replace Other Components	/0
	Appendix A	
Program Conversion Errors (PCE) Messages	Introduction	73
-	Appendix B	
I/O Modules	Supported I/O Modules Unsupported I/O Modules.	75 76
	Appendix C	
Performance Expectations		79
	Appendix D	
Advanced Modules	Use Advanced Modules in a Logix System	81
	Appendix E	
Migrating MicroLogix 1500 controllers to CompactLogix Index	RSLogix Project Migrator tool	83

About This Publication

This document focuses on converting an SLC program to a Logix program and migrating the existing SLC I/O to an Ethernet network thereby helping to leverage the existing I/O and minimize cost and risk. This document can be used in the planning stages to help identify issues so that you can anticipate the work involved in the conversion. The ideas presented in this document require Studio 5000 Logix Designer software version 21 or later and RSLinx[™] software version 2.59 or later.

This document focuses on converting an existing SLC program to a CompactLogix[™] controller. If you want to convert your SLC program to a 1756 Logix controller the process is similar to what is presented in this manual.

The logic converter tool used for SLC also supports conversion of MicroLogix program to CompactLogix. Refer to Appendix E in this document for a brief guidance on converting MicroLogix 1500 program to CompactLogix.

Studio 5000 Environment The Studio 5000[™] Engineering and Design Environment combines engineering and design elements into a common environment. The first element in the Studio 5000 environment is the Logix Designer application. The Logix Designer application is the rebranding of RSLogix 5000 software and will continue to be the product to program Logix5000[™] controllers for discrete, process, batch, motion, safety, and drive-based solutions.

The Studio 5000 environment was introduced in version 21.



The Studio 5000 environment is the foundation for the future of Rockwell Automation engineering design tools and capabilities. The Studio 5000 environment is the one place for design engineers to develop all of the elements of their control system.

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
SLC EtherNet Adapter User Manual, publication <u>1747-UM076</u>	Reference guide for the EtherNet/IP Adapter Module.
SLC EtherNet Adapter Installation Instructions, publication 1747-IN521	Installation instructions for the EtherNet/IP Adapter Module.
Converting PLC-5 or SLC 500 Logic to Logix5550 Logic Reference Manual, publication <u>1756-RM085</u>	Information on converting a PLC-5 or SLC 500 Logic to Logix5550.
CompactLogix 5370 Controllers User Manual, publication 1769-UM021	Describes how to install, use, and troubleshoot CompactLogix controllers.
CompactLogix Controllers Specifications Technical Data, publication <u>1769-TD005</u>	Provides CompactLogix controllers specifications.
Industrial Automation Wiring and Grounding Guidelines, publication <u>1770-4.1</u>	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, <u>http://www.ab.com</u>	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at

<u>http://www.rockwellautomation.com/literature/</u>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Overview

Why Convert	Migration solutions help you to achieve increased productivity and lessen your risk of maintaining your legacy equipment. Work with a supplier that has the product, service, and industry knowledge to partner with you on an upgrade strategy that will help you maximize your competitive advantage. Rockwell Automation works with you to outline a plan to accomplish the following: • Lower conversion time and labor costs
	Reduce risk by preserving existing field wiring connections
	• Lower engineering costs
	Minimize production downtime
What Is Needed	You need the following items for your migration project:
	B SL ogix 500 version 8.0 or later
	CompactLogix Controller
	 Studio 5000 Logix Designer software version 21, or later, with RS Logix Project Migrator Tool version 3.0 or later
	– Integrated Architecture Builder version 9.6.0.4 or later
	1. Go to <u>http://www.rockwellautomation.com</u> .
	2. Click the Support tab, under Selection, Design, and Configuration Tools.

3. Click System Configuration.

Figure 1 - System Configuration

Rockwell Automation	LISTEN. THINK, SOLVE!		Search	Rockwell Automation Worldwide
Products & Technologies	► Solutions & Services ►	News & Innovation	Training & Events ▶ Sales & Partne	s ▶ Support ▼ About Us ▶
合 Home				
(mit)	Support Resources	Drivers, Software and Downloads	Selection, Design and Configuration Tools	Product Resources
	 Get Support Now 	Drivers	Connected Components Tools	 Literature Library
Start Start	 Technical Support Center (Login required) 	 Firmware Updates 	 Integrated Architecture Tools 	 Product Compatibility & Download Center
S	Search Knowledgebase	 Network Resources 	Product Drawings	Product Catalogs
A A A A A A A A A A A A A A A A A A A	(Login required)	Sample Code	Product Selection	Product Certifications
	 Explore The Forums (Login required) 	 Software Activations & Transfers 	Product Tools & Litilities	 Silver Series
		 Software Downloads 	System Configuration	Product Data Sheets

On the System Configuration page, you can order the full version or download the light version of Integrated Architecture Builder. The light version is fully functional but significantly smaller because it does not contain all of the individual product documentation supplied with the full version.





SLC EtherNet/IP Adapter

The 1747-AENTR adapter module enables CompactLogix and ControlLogix processors to control SLC I/O modules. The adapter is primarily designed to enable migration of existing SLC controlled systems to Logix-based systems.

The adapter mainly acts as a gateway between the SLC backplane and EtherNet/IP and typically replaces an SLC controller in the 1746 rack. On remote SLC racks, it replaces the 1747-ASB module or the ControlNet adapters, catalog numbers 1747-ACN15 and 1747-ACNR15.

Control of the backplane I/O is accomplished with a CompactLogix or ControlLogix controller communicating through an EtherNet/IP router in the Logix backplane, across EtherNet/IP, and into the 1747-AENTR gateway.

As a gateway between the SLC backplane and EtherNet/IP, the 1747-AENTR module is a CIP server (for both Explicit Messaging and I/O) on the Ethernet port, and an SLC host on the 1746 backplane.

Connections can be made to supported 1746 and 1747 analog, digital, and specialty I/O modules installed in the backplane.

IMPORTANT See <u>Appendix B</u> for a list of supported and unsupported I/O modules.

1747-AENTR Connections

Exclusive Owner, Input Only, and Listen Only connections are Class 1 connections. The 1747-AENTR module supports a combined total of 96 Class 1 connections:

- One Exclusive Owner connection per slot
- A combination of 5 Input Only or Listen Only connections per slot

The 1747-AENTR module supports a maximum of 8 Class 3 connections. Class 3 connections are typically a connected ladder-triggered MSG instruction to the 1747-AENTR module.

1747-AENTR and Rack Optimization

A major difference between using the 1747-AENTR adapter with SLC I/O modules and any other Logix compatible I/O system is that the 1747-AENTR adapter does not support a Rack Optimized connection type. This means that each module is an individual connection to the controller. These connections must be taken into account when converting the SLC controller. The main considerations are the effect on the Logix controller's total number of connections and the allowable RPIs to the modules in the 1747-AENTR chassis.

Exclusive Owner, Input Only, Listen Only, and None Connection Types

People familiar with SLC programing and I/O may not be familiar with how Logix handles programming and I/O. In simple terms, all I/O in a Logix controller is placed in an I/O tree. All I/O modules in the I/O tree can have multiple types of connections that transfer the I/O data into the Logix controller's memory. Below are some basic definitions of the types of connections that can be made to various 1746 I/O modules.

None - A method of establishing communication to a 1747-AENTR module that enables connection to individual modules within the 1747-AENTR module chassis by using individual connections. After a None connection is configured to a 1747-AENTR module, each module that you desire to communicate through this connection must also be configured under the 1747-AENTR module by using any type of individual module connection (Exclusive Owner, Input Only, or Listen Only). Only the 1747-AENTR module supports a None connection type. A None connection does not affect the 96 total available Class 1 I/O connections on the 1747-AENTR module.

- Exclusive Owner There can be only one Exclusive Owner connection to the each module. The Exclusive Owner connection is the one and only connection that controls outputs (analog or discrete) to that module. The Exclusive Owner connection is the one and only connection to send configuration data to that module. An Exclusive Owner connection to a device is the only connection that determines the mode (Prog or Run) of that particular device. Each Exclusive Owner connection does subtract 1 from the 96 total available Class 1 I/O connections on the 1747-AENTR module.
- Input Only There can be as many as 5 Input Only connections to the same module. This connection type lets multiple Logix controllers receive incoming data from the same I/O module. If the connection is to an I/O device that requires configuration or output data, the Input Only connection does not send any configuration or output data. You can get Input Only data with or without an existing Exclusive Owner connection. Each Input Only connection subtracts one from the 96 total available Class 1 I/O connections on the 1747-AENTR module.
- Listen Only There can be as many as 5 Listen Only connections to the same module. This connection type is identical to an Input Only connection with two differences:
 - Either an Exclusive Owner or Input Only connection must exist and be working to the I/O module before a Listen Only connection can work.
 - The Exclusive Owner or Input Only connection and the Listen Only connection must all be set to Multicast. Each Listen Only connection subtracts 1 from the 96 total available Class 1 I/O connections on the 1747-AENTR adapter.

Add I/O Modules Online

RSLogix 5000 software, version 15.02.00 and later, or Studio 5000 environment, version 21.00.00 and later, the 1747-AENTR module, and all supported 1746 I/O modules support adding I/O modules online and Module Discovery. However, this feature is supported only in 1756 controllers. CompactLogix controllers do not support adding I/O modules online or Module Discovery.

Using the 1747-AENTR Module in a Redundant Logix System

The 1747-AENTR is not compatible for use in a ControlLogix redundant system using a 1756-SRM, 1756-RM, or 1756-RM2.

SLC to Logix Memory Comparison

When choosing a Logix controller to migrate to, you must consider the memory size of your existing SLC program and in what type of Logix controller the program will fit after conversion. SLC maximum memory sizes vary from 1 KB to 64 KB. Logix controllers vary in maximum memory size from about 380 KB to about 33 MB. While no two SLC programs' memory usage before and after conversion is the same, a good rule of thumb is that a full 32 KB SLC program converts to a Logix program size of about 360 KB. So in general, SLC programs of less than 32 KB fit into any type of Logix controller while a full 64 KB SLC program fits only in Logix controllers with at least about 800 KB of memory.

Scan Time ComparisonThe Logix controller has a significant advantage over the SLC controller in regard to program scan time. While each situation is unique, it is likely you'll see a reduction in overall scan time when you convert to a 1756-L7x controller or a CompactLogix 5370 controller. In many cases a scan time reduction is beneficial, but there can be instances where this is not ideal and can disrupt an existing process. Consider this in your conversion process and make the necessary adjustments to scan time as needed.

While some conversions involve converting a single SLC controller to a single Logix controller, there are cases where you want to convert multiple SLC controllers and combine them into a single Logix controller. With the significant decrease in scan time, this can be possible without any decrease in throughput or performance.

After the conversion, you could expect a decrease of 50...80% in overall program scan when running in a Logix controller as compared to an SLC controller. For more information on converting an SLC 500 program, refer to the Converting PLC-5 or SLC 500 Logic to Logix-Based Logic, publication <u>1756-RM085</u>.

Local Rack SLC 500 I/O Modules

1746 I/O modules contained within the same chassis as the SLC controller are considered local I/O. In simple terms, the SLC controller can be removed and a 1747-AENTR installed in its place. It is important to note that SLC 500 local I/O, both analog and discrete, was generally scanned fairly quickly, with the major contributor to throughput being program scan. Because SLC 500 local I/O is changed during the system conversion to remote I/O on Ethernet, I/O scan time is greatly reduced. This means that when selecting the RPI of the I/O in the chassis with the 1747-AENTR module, you must balance desired performance with RPIs that are valid for the number of I/O modules in the chassis.

IMPORTANT Modules requiring G-file configurations cannot be in a remote rack to a Logix controller.

See <u>Appendix C</u> for information on performance expectations.

Remote Rack SLC 500 I/O Modules

IMPORTANT See <u>Appendix B</u> for a list of supported and unsupported I/O modules.

Many SLC systems have I/O remotely located from the SLC controller. The I/O can be scanned by a 1747-SCNR (ControlNet) module or a 1747-SN (RIO) module. The adapters used can be a 1747-ACNR (ControlNet) module or a 1747-ASB (RIO) module. The 1747-SCNR/1747-SN modules scan I/O and place the data in a combination of I1 Input, O0 Output, M1 Input, and M0 Output files. Because the 1747-SCNR module and the 1747-SN module are not supported, they are removed from the converted system and the 1747-ACNR module and the 1747-ASB module are replaced with a 1747-AENTR module and scanned directly by the Logix controller. After the replacement of the various modules the data must be MOVed/COPied to/from the original I1, O0, M1, and M0 locations to the new Logix tag locations. The exact process of these moves is beyond the scope of this document.

The scanning of the remotely-located I/O in the SLC system was at a slower rate than the scanning of local SLC I/O. After conversion to a Logix system, the scan rate of the remote I/O scanned on Ethernet via the 1747-AENTR module will be similar to that of the original SLC system.

Some SLC systems can perform Block Transfer Reads (BTR) and Block Transfer Writes (BTW) over remote I/O via the 1747-SN module. This is a specialized function and requires a more detailed description. The 1747-AENTR module does not support the 1747-SN module, but the racks communicated with by the 1747-SN module contain a 1747-ASB module that can be replace by a 1747-AENTR module. If your existing SLC system is using BTR and BTW instructions over remote I/O via the 1747-SN module, the BTR/BTW can be replace by a module connection in the Logix Designer application. Expect this part of the conversion to take additional work and time.

Overall Performance Expectations

While each conversion situation is unique, it is likely that the scanning of I/O could be slower in a Logix system while the program scan is faster. Overall performance and throughput is likely to be better than the existing system.

If the current system has very stringent performance characteristics, we recommend you perform a more detailed performance analysis to verify the Logix performance in advance of your migration.

Logix Controller Boot Time

As Rockwell Automation moves forward with technology and adds more functionality into the controllers, boot time can be affected. Here are some of the reasons:

- More tasks are performed at startup, such as: memory validity checks, safety diagnostics, controller health, and security tests.
- As memory sizes increase, so does the power required to back up that memory.
- The controller does not enter the 'RUN' condition until there is enough energy stored to tolerate a potential loss of power. Larger capacitors require longer charge-up times.
- Certification requirements continue to drive more start-up diagnostics and code validation.
- SLC processors' power-up times were relatively small, taking only several seconds. Some Logix controllers can take as long as 40 seconds to power up.

Therefore, you can expect the boot time in the Logix controllers to be greater than in your SLC controllers.

Synchronous Versus Asynchronous I/O Scans

The SLC 500 processor maps I/O data into Input and Output data table files. The I/O data is updated synchronously to the program scan so you know you have current values each time the processor begins a program scan and that the I/O data does not change during the program scan. A Logix controller references I/O that is updated asynchronously to the logic scan.

If you need to maintain I/O data integrity throughout the program scan and/or you need to maintain synchronous I/O data transfers in the Logic controller you must use a CPS copy instruction. Please reference KB ID 50235 for more information on how to use the CPS instruction.

SLC I/O Local and Remote Rack Size

The SLC 500 systems had a maximum single-chassis size of 13 slots, through the use of various cables, multiple chassis could be connected together to create an I/O rack that extended up to 30 slots. RSLogix 5000 software version 20.00.00 with the 1747-AENTR module version 1.1 supports a maximum chassis size of 13 slots and only one chassis. Logix Designer Application version 21.00.00 or later with the 1747-AENTR module version 2.1 supports up to 30 modules and up to 3 chassis.

IMPORTANTRSLogix 5000 software version 20.00.00 with any version of the 1747-AENTR
module supports a single chassis with up to 13 slots. You must have Logix
Designer Application version 21.00.00 or later and a 1747-AENTR module
version 2.1 or later to support up to 30 modules.

Keeping I/O

With the introduction of the 1747-AENTR module, you can potentially lower the risk, decrease conversion time, and lower the cost of converting an SLC system to a Logix system. Studio 5000 Logix Designer version 21 and later lets you keep your existing SLC I/O modules while migrating to a Logix controller. The existing SLC I/O can be added to the Logix controllers' I/O tree by replacing the SLC controller or SLC adapter with a 1747-AENTR module. No changes are needed to individual SLC I/O modules, but new EDS files have been developed for the existing supported modules. These new EDS files are installed with RSLinx software version 2.59. The EDS files can be verified in RSLinx software by viewing the modules' EDS file. The correct EDS files have a ModDate of 2011; incorrect files have a ModDate of 1999.

IMPORTANT See <u>Appendix B</u> for a list of supported and unsupported I/O modules.

RSLinx software version 2.59 installs new EDS files for all 1746 supported I/O modules. However, the 1747-AENTR EDS file installed by RSLinx software version 2.59 is not the latest version. You must update the 1747-AENTR EDS file to the latest version, which is currently version 2.3. Common symptoms of creating an RSLogix 5000 project with an incorrect 1747-AENTR EDS file include the following:

- Incorrectly getting 'Module Configuration Rejected fault code 16#0009' to a properly configured module under the 1747-AENTR module
- Inability to convert an RSLogix 5000 project from one controller type to another
- Inability to open a valid project on a different computer

The corrective actions include uninstalling the incorrect EDS file and updating to the correct version EDS file, possibly deleting the 1747-AENTR module and its children from the I/O tree, and exporting and importing the project. If you are using EDS revisions earlier than 2.3 and you right-click on the 1747-AENTR module, you do not see a selection for 'Upload EDS from device'. If you are using EDS revision 2.3 or later and you right-click the 1747-AENTR module, you see a selection for 'Upload EDS from device'.

Migration Considerations

Document Current System Layout

Begin planning your migration by documenting your existing system as a reference point. This enables you to consider the available options and find a solution that best meets your existing and future requirements. The PLC-5/SLC Interactive Migration Planner tool provides general guidelines as you migrate your SLC 500 system to a Logix based solution.

PLC-5/SLC Interactive Migration Planner

Go to <u>http://www.rockwellautomation.com</u> and click on the Products & Technologies tab, under Our Portfolios, click Integrated Architecture.

- 1. Go to http://www.rockwellautomation.com.
- 2. Click the Products & Technologies tab.
- 3. Under Our Portfolios, click Integrated Architecture.



4. Under Application Tools, click Integrated Architecture Tools.



- 5. Click the Choosing An Architecture tab.
- 6. Download the PLC-5/SLC Interactive Migration Tool.



7. Use the tool to help plan your migration.



Define Future Requirements

As you investigate the prospect of upgrading current control systems to newer technology, it is important to factor in all aspects of the migration. Deciding how to phase in the new system can be challenging due to conversion time and physical considerations. Rockwell Automation has tools to assist with the conversion of the program code to minimize the engineering design time. But, what about the physical layout of the new system? Does it make more sense to leave the existing legacy I/O and wiring in place and save the I/O conversion for a later date? Or should the entire system be upgraded all at once? How might the hardware costs for each of these scenarios be affected?

The process for converting your SLC program to a 1756 Logix controller is similar to what is presented in this manual.

Device-level Ring Topologies

While the 1747-AENTR adapter can be a member of a ring, the adapter does not support being an Active Ring Supervisor or a Back-up Supervisor. For more information on Ethernet network rings and ring supervisors, see the EtherNet/IP Embedded Switch Technology Application Guide, publication <u>ENET-AP005</u>.

Using DeviceNet Network

Existing SLC systems that use 1747-SDN modules need to replace the 1747-SDN module with a different DeviceNet scanner because the 1747-SDN module is not supported by the 1747-AENTR module. Depending on the application and Logix processor selected, likely choices include a 1756-DNB module, a 1769-SDN module, or a 1788-EN2DN module.

The 1747-SDN module scans I/O and places the data in a combination of I1 Input, O0 Output, M1 Input, and M0 Output files. The 1747-SDN module needs to be replaced in the converted system with a different DeviceNet scanner. After the replacement, the original 1747-SDN module data must be MOVed/ COPied to/from the original I1, O0, M1, and M0 locations to the new Logix tag locations.

IMPORTANT The exact process of these moves is beyond the scope of this document; expect this part of the conversion to take additional work and time.

Use of Advanced Modules

The 1746-HSCE, 1746-QS, 1746-BAS/B, and the 1746-BAS-T modules are considered advanced modules because they transfer Input data, Output data, and in an SLC environment M0 and M1 files. In the Logix Designer application, connections are established to these modules by using an Exclusive Owner Advanced connection. The Exclusive Owner Advanced connection enables the transfer of the additional data supplied by the 1746 modules M0 and M1 files. Advanced connections transfer Input, Output, M0, and M1 data from the 1746 module via a single connection in the Logix Designer application. This data in the RSLogix 500 environment was obtained in the equivalent of two separate transactions.

Advanced modules do require some additional set up and configuration. Advanced modules also do not have descriptive tag names like most nonadvanced 1746 I/O modules. All Advanced modules require additional steps and programing to migrate.

See <u>Use Advanced Modules in a Logix System on page 81</u> for information.

Communication With an SLC Controller Over DH485, DH+, Ethernet, or Serial Networks

Be aware of other networks and take them into account when planning a conversion. This is a brief overview of networks that can be present in the existing architecture.

TIP You can also use products from various Rockwell Encompass Partners for support on a specific protocol.

If after the conversion you need to keep communication with existing nodes, various communication modules can facilitate this messaging.

Network	Modules	See Publication
DH485 network	1756-DH485 communication module	<u>1756-UM532</u>
DH+ network	1756-DHRIO communication module	<u>1756-UM514</u>
Ethernet network	1756 Ethernet modules	ENET-UM001

You can take advantage of the built-in RS232 port on the SLC controller as an inexpensive way to communicate to other devices. If this communication port is to be maintained after the conversion, you need to consider the following.

- The SLC serial port supported multiple protocols most of which are also supported by Logix controllers. However, the SLC controller supported Modbus RTU Master as a built in protocol. Logix controllers do not offer Modbus as a built in protocol, but there is application code that can configure the Logix controller to talk through the serial port as either a Modbus RTU master or slave. See KB ID 42662 for details.
- Not all Logix controllers have a serial port. During the design phase of the conversion, be sure that the selected Logix controller supports serial communication if it is needed. Note that Logix controllers with a USB port cannot access that port for serial communication.
 - **TIP** For RS-232 network communcation, you can use a 1734-RS232 module or other third party options available from companies such as ProSoft.

The 1747-AENTR adapter module uses 470 mA at 5V DC of chassis backplane power and 0 mA at 24V DC. In general the 1747-AENTR module replaces some type of SLC controller, 1747-ANC(R) module, or 1747-ASB module. Depending on exact module configuration of the chassis and exact type of 1746 power supply used, inserting a 1747-AENTR module into the existing chassis can put you over the current rating of the power supply. Before the conversion, investigate what type of module the 1747-AENTR module is replacing, and does inserting the 1747-AENTR module into the current limit of the power supply.

TIP

A 5/01 controller uses 90 mA at 5V DC, a 5/03 controller uses 500 mA at 5V DC, a 5/04 controller uses 1000 mA at 5V DC, a 1747-ASB module uses 375 mA at 5V DC, and a 1747-ACNR module uses 900 mA at 5V DC. Check the most recent publication to verify each modules current specification.

1747-AENTR Backplane

Power Considerations

Using Integrated Architecture Builder to Plan Hardware Migration

Once you have planned your overall migration approach, let Integrated Architecture Builder (IAB) help plan the details. The SLC migration wizard embedded in IAB steps you through the system configuration process, letting you make the decisions on which components you prefer to keep and reuse and which components you prefer to replace. If you choose to reuse the SLC I/O modules, IAB verifies module support and power supply loading and helps you layout the new EtherNet/IP network.

This section uses the SLC/PLC Migration Wizard within Integrated Architecture Builder to assist with the conversion of the existing SLC hardware to a CompactLogix system. The process for converting your SLC program to a 1756 Logix controller is similar to what is presented in this manual.

Replace Only the Local SLC Controller

 Go to Start > Programs > Rockwell Automation > Integrated Architecture Builder > Integrated Architecture Builder or double-click the Integrated Architecture Builder icon on the computer desktop to launch IAB.

The IAB opening dialog box appears.

2. Click New Project.



3. In the Workspace Name text box, type an appropriate name, such as 'SLC Migration Wizard', and click OK.

Create New Workspace		×
Generic Workspaces	Workspace Name: IAB_proj Location: C:\Program Files\PST\RA_IAB\IAB_proj Set as the default location Description: Creates a new workspace, containing no system information. If you want to create subsystems, you will need to create a system view to continue.	

4. Under Wizard View, click SLC Migration.



Clicking on the wizards listed under Available Assistants provides an overview of the wizard.



5. In the SLC Migration Chassis Selection dialog box, click Add Chassis.

SLC Migration Chassis Selection

IAB opens the Add Chassis dialog box.

6. Click OK to accept the default name (SLC001) for the new chassis.

IAB opens the SLC Migration Module Selection dialog box. This is where you make the conversion selections for this chassis. Notice the different areas of this window.



7. Select your chassis size and choose power supply.



8. From the Processor module list, expand the Processor heading and drag your processor module to slot 0 of the SLC chassis.

Because IAB has found more than one possible CompactLogix controller migration option, the SLC Migration Conflict Resolution Dialog box appears.

SLC MIGRATION PROCE	SSOR OPTIONS	×
1747-L553	SLC 5/05 Con There are multiple po	troller, 64K Memory
Classification	Migration Ethernet Adapter	Description
Adapter	1747-AENTR	SLC to EtherNet/IP Adapter
1		
Classification	Migration Processor	Description
Processor	1769-L36ERM	CompactLogix 5370 L3 Controller, 3Mb Memory, 16 Axis CIP Motion, w/Supercap Backup
Processor	1769-L24ER-QB1B	CompactLogix 5370 L2 Controller, 2 EtherNet/IP ports, 750KB memory, 16 DC in, 16 DC out, up to 4 1769 I/O expansion modu
Processor	1769-L24ER-QBFC1B	CompactLogix 5370 L2 Controller, 2 EtherNet/IP ports, 750KB memory, 16 DC in, 16 DC out, 4 Universal Analog in, 2 Analog o 🔤
Processor	1769-L27ERM-QBFC1B	CompactLogix 5370 L2 Controller, 2 EtherNet/IP ports, 1MB memory, 16 DC in, 16 DC out, 4 Universal Analog in, 2 Analog out
		OK Cancel Help

TIP

Conflict resolution dialogs appear when you must make a decision about the conversion. The information in the dialog box is specific to the action you are performing. In this case, we must select the CompactLogix processor that we wish to use.

9. Select a processor in the list and click OK.

In this example, we show the 1769-L36ERM module.

IAB adds processors to both the SLC chassis and the replacement CompactLogix chassis. Additionally, IAB also adds a 1747-AENTR Ethernet adapter module to the retained I/O SLC chassis at the bottom of the display.



- 10. Repeat steps 8 and 9 to fill remaining slots.
 - **TIP** If you incorrectly place a module, simply right-click the module and click Remove Module to try again.

The majority of 1746 and 1747 discrete, analog, and specialty modules are compatible with the 1747-AENTR adapter.

For a list of supported and unsupported modules, see <u>I/O Modules on</u> page 75.

If you have a module that is not compatible, the following warning occurs.

IAB	×
♪	Exact match for 1747-SN does not exist Contact RA Sales or Tech Support for further selection assistance
	OK

IMPORTANT Modules not supported as part of a retained I/O solution, when connected to a Logix controller, are not placed into the lower chassis in IAB.

- 11. Once the local SLC chassis is complete, click OK.
- 12. In the SLC Migration Chassis Selection dialog box, click Generate Hardware to create the wizard-defined CompactLogix configuration in IAB.

SLC Migration Chassis Sele	ction	×
Chassis Configurations: Chassis Name SLC001 SLC002 - Remote		
Add Chassis	Edit Chassis	Delete Chassis
Generate Hardware	Cancel	Help

13. Click the Hardware tab *in the lower left corner of the IAB window.*



14. Click the SLC_Migration.1_SLC001 chassis to see the hardware.

This chassis contains all of the SLC I/O from the local rack that we replaced. A 1747-AENTR module has been added to connect this I/O remotely over Ethernet to the CompactLogix controller that is replacing our SLC processor.

15. Click the save icon to save your project.

Replace the Local SLC System with CompactLogix System

Although retaining the SLC I/O when converting to a Logix system can save on re-wiring costs, adding a controller and a power supply to an existing control panel can prove to be impossible due to physical space limitations. In such cases, the best SLC conversion solution can actually involve converting the I/O to the 1769 or POINT I/O[™] platforms in addition to converting to a Logix controller.

 Go to Start > Programs > Rockwell Automation > Integrated Architecture Builder > Integrated Architecture Builder or double-click the Integrated Architecture Builder icon on the computer desktop to launch IAB.

The IAB opening dialog box appears.

2. Click New Project.

The Create New Workspace dialog box appears.



3. In the Workspace Name text box, type an appropriate name, such as 'SLC Migration Wizard', and click OK.

Create New Workspace		×
Generic Workspaces Generic Workspaces With Hardware With Network With Software CompactLogix Subsystem Connected Components Workspaces Micro800 Subsystem Migration Workspaces Witro800 Subsystem Nigration Workspaces Nigration Nigration Workspac	Workspace Name: IAB_proj Location: C:\Program Files\PST\RA_IAB\IAB_proj Set as the default location Description: Creates a new workspace, containing no system information. If you want to create subsystems, you will need to create a system view to continue.	

4. Click SLC Migration in the Wizard View.

TIP

Click Available Assistants for more information about each assistant.



5. In the SLC Migration Chassis Selection dialog box, click Add Chassis. IAB opens the Add Chassis dialog box.

Chassis Name		
	Add Chassis	
	Enter new chassis name:	
	SLC001	
Add Changing	ОК	Cancel
Add Chassis		

6. Click OK in the Add Chassis dialog box to accept the default name for the new chassis (SLC001).

IAB opens the SLC Migration Module Selection dialog box. This is where you make the conversion selections for this chassis. Notice the different areas of this window.



7. Select your chassis size and choose power supply.



8. From the Processor module list, expand the Processor heading and drag your processor module to slot 0 of the SLC chassis.

Because IAB has found more than one possible CompactLogix controller migration option, the SLC Migration Conflict Resolution Dialog box appears.

SLC MIGRATION PROCESSOR OPTIONS			
1747-L553	SLC 5/05 Cont	roller, 64K Memory	
There are multiple possible configurations allowed. Please select which configurations are desired.			
Classification	Migration Ethernet Adapter	Description	
Adapter	1747-AENTR	SLC to EtherNet/IP Adapter	
·			
Classification	Migration Processor	Description	
Processor	1769-L36ERM	CompactLogix 5370 L3 Controller, 3Mb Memory, 16 Axis CIP Motion, w/Supercap Backup	
Processor	1769-L24ER-QB1B	CompactLogix 5370 L2 Controller, 2 EtherNet/IP ports, 750KB memory, 16 DC in, 16 DC out, up to 4 1769 I/O expansion modu	
Processor	1769-L24ER-QBFC1B	CompactLogix 5370 L2 Controller, 2 EtherNet/IP ports, 750KB memory, 16 DC in, 16 DC out, 4 Universal Analog in, 2 Analog o	
Processor	1769-L27ERM-QBFC1B	CompactLogix 5370 L2 Controller, 2 EtherNet/IP ports, 1MB memory, 16 DC in, 16 DC out, 4 Universal Analog in, 2 Analog out	
		OK Cancel Help	

TIP

Conflict resolution dialog boxes appear when you must make a decision about the conversion. The information in the dialog box is specific to the action you are performing. In this case, we must select the CompactLogix processor that we wish to use. 9. Select a processor in the list and click OK.

In this example, we show the 1769-L36ERM module.

IAB adds processors to both the SLC chassis and the replacement CompactLogix chassis. Additionally, IAB also adds a 1747-AENTR Ethernet adapter module to the retained I/O SLC chassis at the bottom of the display.

SLC Migration Module Selection			×
SLC I/O Replace With CompactLogix Banks Chassis Size Power Supply 1 4 * 1746-P3 2 0 7 1746-P1 7 3 0 7 1746-P1 7 3 5 0 7 1746-P1 7			-
Adapter Gom. Interface I/O Module Motion Motion	1747-L553	-	•
E Scanner	1769-L36ERM	Migrated Chassis	
Image: Specialty Module Image: Specialty Module	Image: Compact Logic S370 L3 Controller, 3Mb Mem Motion, up to 30 1769 I/O expansion modul connections	[3] [4] [5] [6] [7] [8] [9] ory w/Supercap Backup, 16 Axis CIP ss, 48 EtherNet/IP and 120 TCP	

- 10. Repeat steps 8 and 9 to fill remaining slots.
 - **TIP** If you incorrectly place a module, right-click the module and click Remove Module to try again.

The majority of 1746 and 1747 discrete, analog, and specialty modules are compatible with the 1747-AENTR adapter.

For a list of supported and unsupported modules, see <u>I/O Modules on</u> page 75.

If you have a module that is not compatible, the following warning occurs.



IMPORTANT Modules not supported as part of a retained I/O solution, when connected to a Logix controller, are not placed into the lower chassis in IAB.

- 11. Once the local SLC chassis is complete, click OK.
- 12. In the SLC Migration Chassis Selection dialog box, click Generate Hardware to create the wizard-defined CompactLogix configuration in IAB.

SLC Migration Chassis Sele	ection	×
Chassis Name SLC001 SLC002 - Remote		
Add Chassis	Edit Chassis	Delete Chassis
Generate Hardware	Cancel	Help



13. Click the Hardware tab *In the lower left corner of the IAB window and click the chassis to see the hardware.*

This chassis contains all of the SLC I/O from the local rack that was replaced.

14. Click the save icon to save your project.

Adding a Chassis

If your system does contain additional remote chassis, you can add to the existing chassis.

1. On the SLC Migration Chassis Selection dialog box, click Add Chassis.

This chassis replaces the remote SLC I/O chassis in your existing system.

2. Name this chassis, for example, SLC002_Remote, and click OK.

- 3. Select the chassis and power supply.
- 4. Choose to retain the SLC I/O for this chassis.

	📴 RA - Integrated Archite	ecture Builder - IAB_proj			- 8 ×
	File Action Option View He				
	L 🗢 🖻 🗹 🕸 🗉 8		<u>8 / 2 / 3 / 9 / 10 / 10 / 10 / 10 / 10 / 10 / 10 </u>		
	🖃 🚯 Workspace 'IAB_proj'	System View - New	System	<u>- 🗆 ×</u>	
	🗈 🎂 New System		System	×	
		SLC Migration Module Selection		<u> </u>	
		SLC I/O Retain		-	
		Banks Chassis Size Power Supply	69 amoto		
		4 ÷ 1746-P1 •		-	
Chassis Size -		2 🗖 0 🛨 1746-P1 🔻			
		3 0 🐺 1746-P1 🔻			
		## SLC			
Power Supply		E Comm. Interface			
rower Suppry	1	I/O Module Motion		.	
		General Others General Scanner	Migrated Chassis		
		E M Specialty Module			
		Engal Processor	0 Adv-Anar - 0		
			(i) assuring		
				• •	

5. Add your remote I/O adapter module to slot 0 of the SLC chassis.

IMPORTANT IAB replaces the 1747-ASB adapter with a 1747-AENTR Ethernet adapter in the replacement SLC remote I/O chassis.

6. Add in the rest of your I/O modules.

TIP If you incorrectly place a module, simply right-click the module and click Remove Module to try again.

The majority of 1746 and 1747 discrete, analog, and specialty modules are compatible with the 1747-AENTR adapter.

For a list of supported and unsupported modules, see <u>I/O Modules on</u> page 75.

If you have a module that is not compatible, the following warning occurs.

IAB	×
⚠	Exact match for 1747-SN does not exist Contact RA Sales or Tech Support for further selection assistance
	ОК

IMPORTANT Modules not supported as part of a retained I/O solution, when connected to a Logix controller, are not placed into the lower chassis in IAB.

7. Once the remote SLC chassis is complete, click OK.

8. In the SLC Migration Chassis Selection dialog box, click Generate Hardware to create the wizard-defined CompactLogix configuration in IAB.

SLC Migration Chassis Selection			
Chassis Configurations			
Chassis Name SLC001 SLC002 - Remote			
Add Chassis	Fdit Chaosis	Delete Chassis	
Generate Hardware	Cancel	Hein	
Generale Hardware		Чан	

- 9. Click the Hardware tab 💣 in the lower left corner of the IAB window.
- **10.** Click on the SLC_Migration.1_SLC002 Remote chassis to see the hardware.

This chassis contains all of the SLC I/O from the remote rack that you replaced. A 1747-AENTR module has been added to connect this I/O remotely over Ethernet to the CompactLogix controller that is replacing our SLC processor.

11. Click the save icon to save your project.

You have three options when converting the second, remote chassis:

- To convert the local SLC I/O, leave the remote SLC chassis in place, add the Ethernet wiring, and rebuild the BOM.
- Add the I/O modules from the second SLC chassis to the new local CompactLogix system.
- Swap out the remote SLC I/O chassis with a more cost-effective FLEX[™] or POINT I/O system.

In either case, this is best done outside the wizard.

Network Connection Options for the Remote (SLC System) I/O Chassis

Connecting I/O systems to a controller is best accomplished by first creating a network connection on the controller itself. Because the remote SLC I/O chassis is configured with a 1747-AENTR Ethernet adapter you can connect it to the CompactLogix chassis by using an Ethernet network.

1. In the Hardware View for the SLC_Migration_SLC001.CpLX chassis, right-click the controller and choose Connect > Connect 'Port 1' to a new EtherNet/IP Network > Standalone Device Level Linear.


2. Click OK to accept the default network name.

Wizard View	Hardware View	- SLC_Migration.2_SLC0	01_2.CMX ×		~
1	T	-/			
Configure cha	ssis Connections	Power supplies			
			New Network Enter New Network Nan EtherNet/IP001	ie Cancel	

3. Click OK to choose default Copper media for the linear topology.

Wizard View	Hardware View	I - SLC_Migration.2_SLC0	01_2.CMX ×
Configure chassis		Power supplies	
			Trunk Type Selection Image: Constraint of the trunk is based in part on the devides you select. Fiber is not possible in all scenarios. Choose default trunk type for this Ethernet topology: Image: Constraint of the trunk type for this Ethernet topology: Image: Comper Image: Comper the topology to a fiber port if you're adding the topology onto a switch. You can do that by drag and drop after the topology has beed added.) Note: You may change your selection later by clicking the "Set Defaults" button on the network status dialog. You may also change the trunk segments individually using the Channel Properies dialog for any node. OK

4. Set the IP address (reference only) of the CompactLogix controller and click OK.

Wizard View	Hardware View - S	LC_Migration.2_SLC00	1_2.CMX ×
72	聖	-1	
Configure chassis	Connections P	ower supplies	
			Enter IP address X Address: II22.168.0.0 OK Cancel

IAB indicates that new connections on this Ethernet network is connected to the CompactLogix controller.

- 5. Click OK.
- 6. Choose the Network tab.

	RA - Integrated Architecture Builder - IAB_	proj5			_ = ×			
File Action Option View Help								
) 🔍 🗱 😫 🤿 🐼 🖓 HA 🗈 🖭 😡 🔤 🕅 😔	91	0					
Workspace 4 ×	Wizard View Hardware View - SLC_Migration.2_SLC001_2.CMX Network View - Linear001 ×		▼ ▼	Properties	# ×			
□ (Workspace 'IAB_proj5' ⊕ → EtherNet/IP001	Image: Configure Config			Network Status Status	ОК			
	EtherNetIP001/Linear001 (Default Processor on Network: SLC_Migration 2_SLC001_2.CMQ							
	SLC_Migration.2_SLC001_2.CMX [192.168.0.0]							
	Linear001 Tab							
	I I DI Infrastructure View Linear001							
	Device Database	φ×	Component Description		# ×			
Notwork View	📃 🔍 Search 👹 Clear 🗙 Hide		Catalog Number:					
	EtherNet/IP	-	Description:					
	B-2 Adapter	_						
	e-III Base Units E-III Block VO							
T T	🔓 🔤 Comm. Interface							
?L ♣A @H ♥N ♥C ++ V	Suprocessor Suprocess	• •						

7. In the Network View, choose the Linear001 tab.

You see an icon representing the CompactLogix controller. You add your remote I/O devices in this view.

8. Select an I/O adapter from the Ethernet device list tab and drag it into the Network View window.



In this example we use the 1794-AENTR adapter module.

You can modify the characteristics of the adapter such as its IP address.

<u>//</u>	0		우우	រិរ	7 7	
in cable wizard	Configure Cabling	Capacity	Trunk Length	Drop Length	Node Number	Help
EtherNet/IP001/L	.inear001 (Di	efault Proce: SLC_Mig	ssor on Network gration.2_SLC00 [192.168.0.0]	SLC_Migration 1_2.CMX [1	n.2_SLC001_2. Flex001 92.168.0.1]	C MX)
					Duj Dor Ch Dis Ad	plicate Device cumentation annel ',' properties ange channel ',' address connect/Delete channel ',' from Network 'EtherNet/IP001/Linear001' Id Accessory

9. Right-click the FLEX adapter and choose Channel properties.



perties and Cabling		
operties Trunk Cable		
Device Name: Address: Controlled by Processor Chassis:	Flex002 192.168.1.14 SLC_Migration.1_SLC001.CpLX	Node Information Flex002 [192.168.0.2]
Connection		Description: FLEX I/O Dual Port EtherNet/IP Adapter Module
Tap Information Tap: Tap Information Tap: Tap not required for last node on Please Note: The appropriate tap you based upon the selected cab	Enterverviewout/Linearout	Power Supply Information Individual E-Tap (switch) Power Supply Existing Power Supply on Auxiliary power Network Network: Position:
Catalog # Description 1585J-M4TBJM-2 Patchcord:	RJ45 Male / RJ45 Male, 4-Conductor, Teal TPE, Fle	x Rated, 2 meters (6.56 feet)

11. Add the I/O modules to this FLEX chassis.

If you need to expand the chassis size to accommodate your needs, follow these steps.

- a. Right-click the Flex001 adapter and choose Goto Chassis to reveal the FLEX adapter in the Hardware View.
- b. Right-click the FLEX adapter and choose Configure Chassis.

Wizard View	Hardware View	- Flex001 🗙	Network View - Linear001
7	#	- 1	
Configure chassis	Connections	Power supplie	s
	Ree Do Co Mon Ad	move Module cumentation nfigure Chassis diffy connection to extremely slot af dd Accessory	D EtherNet/IP001/Linear001

c. Set the value for the Number of Slots and click OK.

Configure 1794 Chassis						
Local Chassis						
Number of Slots						
🛽 🕂 Slot(s)						
· · · · · · · · · · · · · · · · · · ·						
Sensor Type						
Split Modules into two sections O 2 Wires O 3 Wires						
Split after slot: 0 🚔						
Cable Length: 💿 1 Ft 🔿 3 Ft						
Wiring Method						
Default Wiring Method O Screw O Spring O Dishell O Distribution Roard O MEMO						
Keep User Settings Keife Disconnects						
Do not use a power supply 1794-PS13 IB5-264 VAC To 24 VDC 1.3A Power Supply 1794-PS3 Input Voltage:120V AC:240V AC 0.64 A on 5V via first module 1.30 A on 24V						
Fower Supply Usage 540.00 mA remaining at 5V (100.00 mA used)						
830.00 mA remaining at 24V (470.00 mA used)						
Advanced Controller Performance Data Processor Chassis controlling this Remote Chassis:						
SLC_Migration.1_SLC001.CpLX						
Use Rack optimized connection to the processor						
OK Cancel Help						

12. Save your project.

Create Project Bill of Material

Follow these steps to get an idea of how much your conversion is going to cost and what is needed.

1. From the Menu Bar, click the Project Bill of Material (BOM) icon.



From this dialog box, we can get a clear view of the material necessary to make the conversion based on the chassis layouts.

roj	ect Bill Of M	aterial		_ [
lty	Catalog #	Description							
		Hardware							
		SLC_Migration.1_SLC001							
01	1747-AENTR	EtherNet/IP Communication module	2050.00	2050.0					
_			Subtotal:	2050.					
		SLC_Migration.1_SLC001.CpLX							
)1	1769-ECR	Right End Cap Terminator	34.50	34.					
01	1769-L36ERM	CompactLogix 5370 L3 Controller, 3Mb Memory w/Supercap Backup, 16 Axis CIP Motion, up to 30 1769 I/O expansion modules, 48 EtherNet/IP a	4500.00	4500.					
л	1769-PA2	120/240V AC Power Supply (5V @ 2 Amp)	277.00	277.					
-			Subtotal:	4811.9					
		SLC_Migration.1_SLC002 - Remote							
1	1747-AENTR	EtherNet/IP Communication module	2050.00	2050.					
			Subtotal:	2050.					
			Total:	8911.					
_		The pricing provided is List Price. Please consult							
-		your local sales person to get your specific pricing.							
-									
-									
_									
-									
_									
-									
	aw all slot pumbe	rs O Droanized BOM C Consolidated BOM C Positional BOM							
200									
		Save to XLS Save to XML Print Close Help							

In addition, the radio buttons along the bottom of the dialog box let you manipulate the information either as a consolidated spreadsheet or by slot location. All of these arrangements incorporate pricing either with List or Custom pricing models.

2. Click Close to close the BOM window.

Notes:

Conversion

Introduction

The Logix Designer application includes a RSLogix Project Migrator that converts an SLC 500 import/export file (SLC extension) into a complete import/export file (L5K extension) for the Logix Designer application.

TIPThe Studio 5000 environment, which includes the Logix Designer application,
was introduced in version 21. If you are using RSLogix 5000 software version
20, the steps are nearly identical.

This section describes the RSLogix Project Migrator Tool and also describes pretranslation file preparation and post-translation examples and tasks.

For a more detailed explanation of the RSLogix Project Migrator, refer to Converting

PLC-5 or SLC 500 Logic to Logix-based Logic, publication 1756-RM085.

IMPORTANT The process for converting an SLC system to a ControlLogix system is similar to converting to a CompactLogix system.

Download the standalone RSLogix Project Migrator

You can download a standalone copy of the RSLogix Project Migrator from the Rockwell Automation <u>Compatibility & Download page</u>.



- 3. Under the Download option, click Find Downloads.
- 4. In the Product Search box, type RSLogix Project Migrator.

The migrator appears in the product list.



- 5. Select the RSLogix Project Migrator from the product list and then click Downloads.
- 6. On the Downloads page, click the show downloads icon.

Compatibility / Download Center > Multi Product Selector > Find Downloads

DOWNLOADS

Available downloads for the selected products. Click on the expand icon to see other v



 On the Available Downloads dialog, select the RSLogix Project Migrator and click the Download Cart button and confirm your selection to start the download.

What to Expect from the RSLogix Project Migrator

The goal of the RSLogix Project Migrator is to reduce the amount of work involved in migrating an SLC 500 program to a Logix project. The RSLogix Project Migrator automatically converts the program logic, but the tool is not the complete solution. Depending on the application, you may need to do additional work to make the converted logic work properly.

The RSLogix Project Migrator produces a syntactically correct import/export file, but the exact intent of the original application could be lost. This loss could be due to differences in rules. (For example, rules of precedence, rules of indexed addressing, or rules of I/O addressing). When there is an error in the translation, the RSLogix Project Migrator records the error in the rung of the Logix routine in which it occurred. You can use that error message to analyze and fix the error.



ATTENTION: After running the conversion process, the resulting import/export file still requires further manipulation. You have to map the I/O and use BTD, MOV, or CPS instructions to place this mapped data into the structures created by the conversion process.

Application Code Conversion

The first step in a procedure of this type is to export the current SLC project into an ASCII text format.

1. From the desktop, double-click the RSLogix 500 programming software icon.



Or, choose Start > All Programs > Rockwell Software > RSLogix 500 > RSLogix 500.

2. From the File menu, choose Open to open the file you want to convert.

RSLogix 500 Pro							
File	View	Comms	Tools	Window	Help		
N	ew	Ctrl+	N				
0	pen	Ctrl+	0				
Ba	ackup P	Ctrl+	B				
Pr	rint Set	up					

The first step is to export the current SLC project into an ASCII text format.

3. From the File menu, choose Save As.

R	RSLogix 500 Pro - SLC_MIG5.RSS							
File	Edit	View	Search	Comms	Tools			
N	ew			Ct	rl+N			
Open Ctrl+O								
C	lose							
Si	ave			Ct	rl+s			
Save As								
B	ackup	Project		Ct	rl+B			

4. Browse to the folder where you are saving the converted program.

5. Set the file type to '.SLC.

Save Program As	×
Path: C:\Lab Files	
Save in: 📙 Lab Files <table-cell-columns> 🚽 🔽 👉 🖽 -</table-cell-columns>	
Name 🔺 🚽 Date modified 🗐 🗸 Type	
No items match your search.	
File name: SLC_MIG Save	
Save as type: Library Files(*.SLC)	
Help	
Export database C Logix C A.I. C A.P.S. Export options	
File PLC Information	
Processor Name : SLC_MIG Station # : 54d	
Processor Type : 1747-L553C 5/05 CPU - 64K Mem. 0S501 Series C FRN 10 and later	
Bevision Note	
Version to	
1	

The RSLogix Project Migrator accepts projects that have been saved as .SLC file type.

6. Click Save to continue.

Additional file export options are presented. For this example, we want to export the entire project, so the default settings here are fine.

xport Mode	
Complete Program Save () Partial Save	OK
xport Options	Cancel
Export Rung Descriptions and Page Titles	
Export Symbols and Descriptions	Help
Annotate Library	

7. Click OK.

After the file is converted, select the export options.

From the Tools menu, select Database >ASCII Export.



The Document Database ASCII Export window displays

8. From the CSV tab, select Export Addr/Symbol Desc. and Instruction Comments, and then click OK.

Data to be exported : —		Destination file names and e	xtensions :
Addr/Symbol Desc.		CEM_PB7_20070727	.CSV
instruction Comments		CEM_PB7_200707271	CSV
Page Title / Rung Desc.	Г		
Symbol Groups		CEM_PB7_200707273	.CSV
Program File Names		CEM_PB7_20070727	
AI/AB Address and Instru Characters per line in ta Treat Source Descriptio	action des arget data on as 5 lir on as 1 lir	scription formatting : base v 20 hes (truncating each line if nece he (truncating from the end if ne	essary)

The Select Export Destination Directory dialog displays.

9. Browse to the folder where you saved the .slc file, and click OK.

The Export Result dialog displays.

Export Results	×
Contents	
EXPORTING ADDRESS/SYMBOL DESCRIPTION DATABASE TO C:\Users\User\Desktop\CEM_P87_20070727.CSV EXPORTING TO CSV FORMAT EXPORT finished.	
EXPORTING INSTRUCTION COMMENT DATABASE TO C:\Users\User\User\Desktop\CEM_P87_200707271.CSV EXPORTING TO CSV FORMAT EXPORT finished.	~
< III	•
OK Save To File	

10. Click OK to close the RSLogix 500 software.

Translate an RSLogix 500 Program to a Logix Designer Program

The RSLogix Project Migrator is an optional install as part of the Logix Designer application installation procedure. Once you have the ASCII text file of the SLC 500 program file, you can convert the logic to its Logix equivalent. In the Logix Designer application, use the following steps.

- 1. Launch the tool from one of two locations:
 - From the Windows Start Menu: Start > Programs > Rockwell Software
 > Studio 5000 Tools > RSLogix Project Migrator
 - From within the Logix Designer application: Tools > RSLogix Project Migrator

Tools	s Window Help
	Options
	Security
G	Documentation Languages
	Import •
	Export
a	EDS Hardware Installation Tool
	Motion P
	Monitor Equipment Phases
	Custom Tools
123	RSLogix Project Migrator
1	ControlELASH

The initial dialog box for the RSLogix Project Migrator appears.



2. Click For SLC-500/MicroLogix to Logix migration.

- 3. Click Browse and locate .SLC file.
- 4. Click open.

By default, the wizard expects to use the default documentation file names that you exported earlier.

\fbox Documentation file(s) associated with the logic file use same name	
	Browse

5. Click next.

In the second step of the translation process, you set the options for the new project you are creating. The Create Alias Tag for existing PLC-5/ SLC Symbols option is selected by default.

When this option is enabled, Logix5/500 symbols will be converted to Logix5000 alias tags.

If disabled, symbols will instead be included in the address description.

🔯 RSLogix Project Migrator	- • ×
Step 2 (of 7):	
Select migration options	
Create Alias Tag for existing PLC-5/SLC Symbols	
When this option is enabled, Logix5/500 symbols will be converted to Logix5000 alias tags. If disabled, symbol text will instead be included in the address description.	
Exit Help < Back	Migrate

Click Migrate.

🔯 RSLogix Project Migrator	
Step 3 (of 7):	
Parsing input	
	Cancel
Status Log:	

If there are any syntax errors during migration, the Syntax Error dialog box appears, showing the line in which the syntax error occurred.

- 6. Resolve any syntax errors by using any of the following actions:
- Edit the error immediately at this dialog box and then click Save & Retry to restart the migration.
- Examine the original application to decide if the area where the syntax error is occurring is something that can be deleted permanently or if it is something that can be removed and then later be recreated in the Logix Designer application.
- Edit the SLC and TXT files by using Notepad.
- Review this table for the most common syntax errors and their descriptions. The migration tool can run into syntax errors within the program and database files. If so, you must correct those errors so that the migration tool can continue the conversion. <u>Table 1</u> shows the more common errors.

Table 1 - Common Conversion Errors

Syntax Error	Description	How to Fix the Error
Invalid symbol name	The RSLogix Project Migrator expects the symbol names to be alphanumeric. RSLogix 500 software enforces these rules, but using 6200 software or manually editing the database files can cause these rules to be broken.	Search for symbol names that are not alphanumeric.
" (quote) within a " (quote)	Quotes are used to denote the start and end of string values or rung/instruction/address comments. If a rung/instruction/address comment contains a quote, the RSLogix Project Migrator doesn't know that it isn't the end of the string.	Either remove the quote or make it a double quote (""). The RSLogix Project Migrator translates the double quote as a single quote within the Logix Designer application.
% within a %	% characters are used to denote the start and end of comments within the program file and occasionally in database files. This type of comment is ignored by the RSLogix Project Migrator. If a comment contains another %, the RSLogix Project Migrator doesn't know that it isn't the end of the comment.	Remove the extra % or make it a double %. The RSLogix Project Migrator treats the double %% as consecutive comments.
Errant characters	The program or database file contains a random character or two that does not fit the syntax of the program or database files. This is more common with manually-edited files than a direct export from RSLogix 500 software.	Remove the errant characters.
Invalid rung syntax	The rung has invalid syntax, such as unmatched parentheses.	Check and fix the rung syntax.

7. Once these errors have been resolved, click Save & Retry.

The parsing is completed as shown below.

📱 RSLogix Project Migrator 🧰 📼	• 🗙
Step 3 (of 7):	
Parsing input	
Cancel	
Status Log:	
Reading C:\Users\USER_MANUAL_6_PICK_PLACE MACHINE_APPLICATION.SL Unknown mnemonic 'IL'. Please resolve to continue. Reading C:\Users\USER_MANUAL_6_PICK_PLACE MACHINE_APPLICATION.SL Application successfully parsed.	*

8. Click Next to select the output file options.

In Step 4, specify the RSLogix 5000 file name you wish to create and where you want to save it, which controller type you are using the output file for, and which version you are using.

🔯 RSLogix Project Migrator	
Step 4 (of 7):	
Specify the RSLogix 5000 file to create, along with a target controlle	er type and version
Output File:	
C:\Migration Files\Mig_file.I5k Browse.	
Controller Type:	
1756-L71 • 27 •	
Exit Help	< Back Next >

Click Browse...

9. Browse to the folder where you want to save the file.

- **10.** From the Controller Type pull down menu, select the controller that you want to use the output file with, and then select the version number.
- 11. Click Next.

In Step 5, decide if you want to keep your existing I/O set up on a separate rack and put your new controller on a rack with a single bridge module; or, if you want to replace all existing I/O modules with newer equivalent modules.

If you choose to keep your existing I/O, any module that is unsupported by the newer controller generates a placeholder tag in the migrated output file.

If you choose to replace all your existing I/O modules with equivalent newer modules, you need to select replacements from a list of suggested modules.

🔯 RSLogix Project Migrator 📃	. • 💌
Step 5 (of 7):	
Select I/O migration strategy	
Keep existing I/O in a separate rack	
Place the new controller in a rack, alongside a single EN2T module (or embedded ethernet, for CompactLogix). The legacy I/O will be located in a separate rack. Unsupported modules will generate placeholder tags.	
Replace all I/O with equivalent newer models	
Presents a list of all I/O modules used by the legacy program. Using the accompa drop-down lists, the user must select a compatible replacement I/O module for ev legacy I/O module.	anying very
Please note that suggested replacement modules should be verified for your application.	
Exit Help Sack	vext >

- 12. To keep existing I/O in a separate rack
 - a. Select the Keep existing I/O in a separate rack option, and click Next. In Step 6, the placeholder tags are created and the application is migrated according to the Controller Type and version selected in Step 4.



To replace all I/O with equivalent newer models

 b. Select the Replace all I/O with equivalent newer models option, and then select the Create placeholder tag(s) option from the drop down list.

In Step 6, the application is migrated.

13. Click Launch RSLogix 5000 to start your project.

In Step 7, the application launches and prompts you to save the imported project file.



14. Browse to where you want to save the project file, and click Import.

The project file is migrated and created in the RSLogix5000 program.

Resolve the Differences in the New Logix Program

Now that the SLC 500 program has been initially converted to a Logix program, you need to look at some of the most common elements that must be addressed for the CompactLogix project to properly control the installed 1746 I/O modules.

TIP See <u>Appendix B</u> for supported and unsupported I/O modules.

SLC Controllers Data Tables and Logix Controller Tags

The SLC 500 processors store all data in global data tables. You access this data by specifying the address of the data you want. A Logix controller supports data that is local to a program and data that is global to all the tasks within the controller. A Logix controller can also share data with other controllers, and instead of addresses, you use tags to access the data you want. Each SLC 500 data table file can store several words of related data. A Logix controller uses arrays to store related data. The RSLogix Project Migrator converts the SLC 500 data table files into Logix arrays.

With a Logix controller, you use a tag (alphanumeric name) to address data (variables). The controller uses the tag name internally and does not need to cross-reference a physical address.

- In conventional programmable controllers, a physical address identifies each item of data.
 - Addresses follow a fixed, numeric format that depends on the type of data, such as N7:8, F8:3.
 - Symbols are required to make logic easier to interpret.
- In Logix controllers, there is no fixed, numeric format. The tag name itself identifies the data.
 - Organize your data to mirror your machinery.
 - Document (through tag names) your application as you develop it.

Resolve Program Code Issues

The RSLogix Project Migrator inserts a Program Conversion Error (PCE) instruction within the appropriate ladder rung to help you identify possible errors with the conversion. To complete the conversion process, you want to locate, analyze, and fix any discrepancies involving the PCE instructions.

TIP	For a complete list of the PCE instruction Message IDs and their descriptions, please refer to <u>Appendix A</u> .
IMPORTANT	After the correction of any errors, you must still spend time running and debugging the machine or process.

Locating PCE Instructions

You can locate all of the PCE instructions by verifying the logic. The Verify>Controller task compiles the Logix program and checks for errors. This is an easy way to see where all of the PCE instructions are because the error checking points them out. To locate the PCE instructions, use the following steps.

1. From the Logic menu, choose Verify> Controller.



Or, from the menu bar, choose the Verify Routine icon.



The bottom of the dialog box displays results.

2. Double-click the error shown in the error window to go directly to the rung where the error occurred.

Er	rors
Ve Ve Ve Er Co	rifying routine 'MainRoutine' of program 'MainProgram' rifying routine '_3_LADDER' of program 'MainProgram' rifying routine '_2_LADDER' of program '_2_LADDER' ror: Rung 1, FCE: Unknown instruction. mplete - 1 error(s), 0 warning(s)
<	
0	Errors 🗟 Search Results 🛃 Watch

TIP

Some Warnings reference bits that are used as outputs in more than one rung, Duplicate Destructive Bits. While using this type of coding is generally not recommended, with careful programming, using the same outputs on several different rungs can be done.

Recognizing the Instructions

Text is appended to the rung comments that have the PCE instruction. The message text begins with asterisks(*) and the words "Generated by RSLogix Project Migrator", and ends with asterisks.

An example of a PCE instruction follows:

*** Generated by RSLogix Project Migrator: Source and destination types may differ *** ";

N: PCE(120, PCE011) COP(I1_008, N23[0], 4);



Resolving PCE Instructions

Once you import the converted Logix project, find each PCE instruction. A PCE instruction highlights a possible conversion error. Delete each PCE instruction and replace it with the appropriate, corrected logic.

Common PCE Issues

Translation greatly reduces the amount of work in a conversion; however, you may still get conversion errors that must be addressed individually.

- A very common error occurs with all Timer related instructions. The timer instruction and its associated elements are compatible between the SLC 500 controller and the Logix platform. However, the SLC 500 controller supports only a .01 or 1 second time base for timers. Logix controllers support a 1 ms time base. The code conversion resulted in an increase of the timer Preset value by an order of magnitude. That is, the original Preset in the SLC 500 controller for this timer was 32767 and now it has been changed to 327670. All related references to this timer have been adjusted automatically, except those that reference a specific bit within the Accum or Preset itself. This can lead to errors on any rung that addresses a Timer.PRE or Timer.ACC because the scaling can be off and can be corrected only by user intervention.
- Another common conversion tool error is related to MSG instructions. Not all SLC 500 MSG instructions convert completely and, after the conversion, you need to verify that the data and path in all MSG instructions are correct.

• Several other SLC instructions may not convert properly or may not have the intended behavior. Among the more significant SLC instructions that can have issues are serial port instructions, Block Transfer instructions, FBC, and PID.

Map PLC/SLC Messages

Map PLC/SLC Messages is a built-in feature of Logix controllers that lets older products that support a data table memory architecture, like PLC-2, PLC-5, and SLC controllers read/write to a Logix controller that has a tag-based memory architecture.

If after the conversion, legacy SLC controllers need to communicate to the converted Logix controller, Map PLC/SLC Messages can facilitate this. See the example below for an overview explaining PLC/SLC Mapping.

 EXAMPLE
 If an incoming message from an SLC controller requests to read data from file

 N7:x, the Logix controller replies with data from tag
 SLC_Reads_This_LogixTag[x].

If an incoming message from an SLC controller requests to write data to file N10:x, the Logix controller places that data in tag SLC_Writes_to_This_LogixTag[x].



Resolving Issues with Physical I/O

Remember, in your new CompactLogix system, all of the 1746 I/O is considered remote, but you are not using remote I/O. Each SLC chassis is connected through the 1747-AENTR Ethernet adapters. This eliminates quite a bit of extra code otherwise required to communicate to remote I/O.

There are three options for resolving physical I/O issues:

- MOV instructions
- CPS instructions
- Aliasing instructions

Each has its advantages and drawbacks depending on the type of data. Ideally, the RSLogix Project Migrator identifies I/O to be converted and offers you options during the conversion process rather than leaving this to you afterwards.

These examples illustrate situations you can encounter when translating your files.

MOV Example

This first rung is used to initialize the configuration for a 1746-NT4 module in slot 5 of the local SLC 500 chassis.



The Dest data location represents an integer array of at least 4 elements. To successfully configure multiple channels, the normally consecutive array elements must be transferred into non-consecutive structures built by the 1746-NT4 module data type.

The original rung can remain, but you need to create a new rung that moves the configuration for the channel to the corresponding module config tag.



This resolves the issue for Channel 0. Additional MOV instructions are required if other channels are used.

CPS Example

In RSLogix 500 software in order for many specialty modules to transfer data over RIO, sophisticated instructions called Block Transfers were used. In the Logix Designer application, these Block Transfers were replaced with the MSG instructions shown below.



The need for messaging to/from these modules is no longer needed because the controller is communicating with them directly through the 1747-AENTR module.

Figure 3 - Original RSLogix 500 Software Block Transfer Instructions



- Data to be written to the remote module in our example, was entered into N11:0 (2 words).
- Data to be read from the remote module into the controller was placed into N13:0 (2 words).

If consecutive I/O groups map to consecutive elements in an array, a CPS instruction must be used. Use a CPS instruction when you copy I/O or Produced/Consumed peer data of more than one DINT. This is the only information you need to create the instructions necessary to replicate the original program functionality.

IMPORTANT Extensive use of the CPS instruction can lock the tag database which could affect other processes.

You can delete the rungs containing the PCE and MSG instructions and replace them with CPS rungs.

CPS	;
Copy File	N110
Dest Adapter_2:3:0	D.Channel_0_Data
Length	2
CPS	
Copy File	
Source Adapter_2:3	I.Channel_0_Data:
Desi	IN I JU
m	Copy File Source Dest Adapter_2:3: Length moves data from the 1747-1/0 module to the array titled N13. N13 is used throu the program. RIO Analog Copy File Source Adapter_2:3 Dest

IMPORTANT	The CPS instruction is intended to be used when copying I/O data or Produced/
	Consumed peer data to/from controller tags. For more information on the use
	of the CPS instruction, see Knowledgebase document KB ID 50235, contact
	your local Allen-Bradley distributor, or Rockwell Automation sales
	representative.

Alias Example

The rung in this routine uses a timer accumulator to simulate an analog output value for a 1746 I/O module. Although this is not very realistic, it does provide an instance in which aliasing can be most used.



In the example rung, a value is being moved into the O3_000 'alias' tag generated by the RSLogix Project Migrator. However, you need to actually tie this tag to a physical output address, namely the output location associated with the 1746 I/ O module.

Aliasing the T4[30].ACC to the physical output address can seem like the right choice, but members of an array cannot be aliased in Logix. Because this instruction manipulates just a single word of data, you can modify the MOV instruction. Based on the I/O configuration, the base output data for the local 1746 I/O module is contained in the 'Adapter_1:x:O' tag.

You need to modify the Dest element of the MOV instruction and delete the PCE instruction.



Replace SLC Processor and Adapters

Mount and wire the CompactLogix system and replace the SLC first slot modules (SLC processor or communication adapter module) with the SLC Ethernet adapter, catalog number 1747-AENTR.

Set the Network Address Switches

The network address switches are set to 999 and DHCP enabled, by default. You can set the network Internet Protocol (IP) address in the following ways:

- Use the network address switches on the module.
- Use a Dynamic Host Configuration Protocol (DHCP) server, such as Rockwell Automation BootP/DHCP.
- Retrieve the IP address from nonvolatile memory.

The adapter reads the network address switches first to determine if the switches are set to a valid number. You set the node address by using the network address switches. Valid settings range from 001...254.



When the switches are set to a valid number, the adapter's IP address is 192.168.1.xxx (where xxx represents the number set on the switches).

The adapter's subnet mask is 255.255.255.0 and the gateway address is set to 0.0.0.0. The adapter does not have a host name assigned, or use any Domain Name System when using the network address switch settings.

If the switches are set to an invalid number (for example, 000 or a value greater than 254 excluding 888), the adapter checks to see if DHCP is enabled. Setting the switches to 888 restores default factory settings.

IMPORTANT	If you set the value of the adapter switch to 888 and then power cycle the module, the following occurs:
	• The DHCP Enabled function is enabled (set to True).
	• The Ethernet link is negotiated automatically. The Auto Negotiate function is set to True.
	• The web server is enabled. The Disabled Web Server function is disabled.
	 The Ethernet ports are disabled. Both ports are re-enabled once the switches are returned to their previous value and power is cycled.

DHCP Enabled and Not Enabled

DHCP Enabled and Not Enabled				
If DHCP is	Then the Adapter			
Enabled	Asks for an address from a DHCP server. The DHCP server also assigns other Transport Control Protocol (TCP) parameters. The 1747-AENTR factory default is DHCP enabled. When you apply power, the module sends a message containing its hardware address to any DHCP server on the network. The server(s) replies by sending a message with an appropriate IP address for the adapter. The adapter responds by acknowledging to a server that the adapter will use the offered IP address.			
Not enabled	Uses the IP address (along with other TCP configurable parameters) stored in nonvolatile memory. When the IP address assigned to the module, as indicated in the four-character dot matrix status display, is changed through the DHCP configuration utility, the DHCP is disabled. When power is cycled to the device, the device uses the new configuration and implements the new IP address.			

Determine Power Requirements

The Ethernet adapter requires 5V DC with current consumption of 470 mA. The power is supplied through backplane from SLC power supply. Remember to consider this requirement when planning your system configuration.

Install the Adapter Module in the Chassis

After you set the appropriate switch assemblies for your adapter module, follow these procedures for installation.

Refer to the Industrial Controller Wiring and Grounding Guidelines publication <u>1770-4.1</u> for proper grounding and wiring methods to use when installing your module.

1. Remove power from the I/O chassis before inserting (or removing) the module.

2. Align the circuit board with the chassis card guide in the left slot.



3. Install the module in slot 0 of the chassis by aligning the circuit board with the chassis card guide.

The 1747-AENTR module must be installed only in slot 0 (leftmost slot) of the chassis.

4. Press firmly and evenly to seat the module in its backplane connectors.

To remove the module, press the releases at the top and bottom of the module and pull it out.



ATTENTION: Do not force the module into the backplane connector. If you cannot seat the module with firm pressure, check the alignment. Forcing the module can damage the backplane connector or the module.

Connect Your Adapter to the Ethernet/IP Network through RJ45 Connection

Connect your 1747-AENTR adapter module to an Ethernet/IP network as shown below.



Wire the RJ45 connectors as shown.

To connect the module to the network, follow these steps.



WARNING: If you connect or disconnect the communication cable with power applied to this module or any device on the network, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

1. Attach the cables with the RJ45 connectors to the two Ethernet ports on the bottom of the module.



2. Attach the other end of the cables to the devices in your network.



3. Configure your 1747-AENTR adapter.

See publication <u>1747-UM076</u> for information on configuring and using your adapter.

If your control system has legacy or competitive operator interface, variable frequency drives, motion control, sensors, or motor control centers, you can migrate those products as well.



Replace Other Components

See the following publications for more information:

- PanelView Plus Terminals
 - For selecting your terminal: VIEW-SG001
 - For installing and operating your terminal: 2711P-UM001
- PowerFlex Drives
 - For selecting your drive: <u>PLEX-SG002</u>
 - PowerFlex* 700S Adjustable Frequency AC Drive Phase II Control (Frames 1...6) Installation Instructions, publication <u>20D-IN024</u>.
 Provide information needed to install and wire a PowerFlex 700S Phase II Adjustable Frequency AC drive.
 - PowerFlex* 700H Adjustable Frequency AC Drive / PowerFlex 700S High Performance AC Drive, Frames 9...14 Installation Instructions, publication <u>PFLEX-IN006</u>. Provides drive mounting and wiring information.
 - PowerFlex 700S High Performance AC Drive- Phase I Control Reference Manual, publication <u>PFLEX-RM002</u> Provides information on specifications and dimensions, mounting, and detailed drive operation for the PowerFlex 700S with Phase I control.
 - PowerFlex 700S High Performance AC Drive Phase II Control Reference Manual, publication <u>PFLEX-RM003</u> Provides information on detailed drive operation for the PowerFlex 700S with Phase II control.
 - PowerFlex 700S High Performance AC Drive Phase II Control Programming Manual, publication <u>20D-PM001</u> Provides information needed to start-up, program and troubleshoot PowerFlex 700S Phase II Adjustable Frequency AC drives.
 - PowerFlex 700S with Phase II Control Technical Data, publication <u>20D-TD002</u> Provides information on options, specifications, ratings, dimensions, derating data, and other product information.
 - PowerFlex 700H Adjustable Frequency AC Drive Programming Manual, publication <u>20C-PM001</u> Provides basic information needed to start-up, program and troubleshoot the PowerFlex 700H Adjustable Frequency AC Drive.
 - Wiring and Grounding Guidelines for Pulse Width Modulated (PWM) AC Drives, publication <u>DRIVES-IN001</u> Provides basic information needed to properly wire and ground PWM AC drives.
- Kinetix Motion Control
 - For information about motion control: <u>GMC-SG001</u>
Program Conversion Errors (PCE) Messages

Introduction

<u>Table 2</u> lists all of the messages that are generated with a PCE instruction. The text is appended to the rung comments that have the PCE instruction. The message text begins with asterisks (*) and the words "Generated by RSLogix Project Migrator", and ends with asterisks.

Table 2 lists the message identifiers, descriptions, and when they are logged.

Table 2 - PCE Messages

ID	Text	When logged
101	The address references a counter's Update Accum (UA) bit field. This is not supported in the Logix Designer application.	Each time a reference to a counter's UA field is encountered (SLC only)
102	The address references a counter's Overflow(OV) or Underflow(UN) field. This has been translated but the translation needs to be validated.	Each time a reference to a counter's OV or UN field is encountered
103	Warning : Status files do not exist in the Logix Designer application. GSV instructions are used in the Logix Designer application to obtain controller information where applicable. This translation must be validated.	Each time a reference to the S file is encountered
105	The address references an indirect file number. It was not translated.	Each time an address reference with an indirect file number is encountered
107	The address reference may have an incorrect index. The translation needs to be validated.	Each time suitable index into the array could not be determined
108	The BTR, BTW or MSG instruction has been translated. However, the translation needs to be validated. These instructions have many parameters that cannot be directly translated and require review.	Each time a BTR, BTW or MSG instruction is translated
109	PLC-5 and SLC s use 0.01 second and 1 second timebases. the Logix Designer application uses a 0.001 second time base. The address references a 's Accumulator (ACC) field. The translation needs to be validated.	Each time a reference to a 's ACC field was encountered
110	PLC-5 and SLC s use 0.01 second and 1 second timebases. the Logix Designer application uses a 0.001 second time base. The address references a 's Preset (PRE) field. The translation needs to be validated.	Each time a reference to a 's PRE field was encountered
113	Follow the <fbc ddt="" or=""> instruction with MOV and FAL instruction on parallel branches to make sure the correct bits are being operated on.</fbc>	Each FBC and DDT instruction
114	Although the PID instruction has been translated, the PID instruction has many parameters that do not translate directly to the Logix Designer application. The translation must be verified.	Each time a PID instruction is translated
115	16-bit parameters have been extended to 32-bit. Verify bit manipulation is correct.	Each time BSL, BSR, BTD instruction is translated
116	The structure of FOR/NXT/BRK statements has changed in the Logix architecture. In the PLC-5 processor, the FOR and NXT instruction enclosed a section of code that was to be iterated multiple times, while the BRK instruction provided a way to break out of the repeating code. In the RSLogix architecture, the FOR instruction calls a given routine a specific number of times, so a NXT instruction is not needed. The BRK instruction works in a similar fashion as in the PLC-5 processor. Because this architecture change is significant, you may need to restructure your logic.	Each time FOR/NXT/BRK instructions are encountered
117	AGA instruction not supported.	Each time a AGA instruction is found
119	CIR/COR not supported.	Each time a CIR or CIO instruction is found

Table 2 - PCE Messages

ID	Text	When logged
120	Source and destination types differ	When source and destination types differ in a COP instruction
121	DFA instruction not supported	Each time a DFA instruction is found
122	ERI/ERO instruction not supported.	Each time a ERI or ERO instruction is found
123	IDI/IDO instruction not supported.	Each time a IDI or IDO instruction is found
124	IIN/IOT instruction not supported.	Each time a IIN or IOT instruction is found
128	SFC routines aren't translated.	Each time a SFR or EOT instruction is found
129	Online edit instructions are not supported.	Each time a SDS, SIZ or SRZ instruction is found
130	User Interrupt instructions not supported.	Each time a UID, UIE or UIF instruction is found
131	DDV instruction not supported.	Each time a DDV instruction is found
132	High Speed Counter instructions not supported.	Each time a HSC/HSD/HSE/ SL or RHC/RAC/TDF instruction is found
133	I/O Interrupt Enable/Disable instructions not supported.	Each time a IID or IIE instruction is found
134	IIM/IOM instruction not supported.	Each time a IIM or IOM instruction is found
135	INT instruction not supported.	Each time a INT instruction is found
136	REF instruction not supported.	Each time a REF instruction (in SLC) is found
137	RPI instruction not supported.	Each time a RPI instruction is found
138	Selectable Timed Interrupt instructions not supported.	Each time a STD/STE or STS instruction is found
139	SUS instruction not supported.	Each time a SUS instruction is found
141	RMP instruction not supported.	Each time a RMP instruction is found
142	RPC instruction not supported.	Each time a RPC instruction is found
143	SVC instruction not supported.	Each time a SVC instruction is found
144	SWP instruction not supported.	Each time a SWP instruction is found
145	SQC instruction not supported.	Each time a SQC instruction is found
146	INV instruction not supported.	Each time a INV instruction is found
147	DCD/ENC instruction not supported.	Each time a DCD or ENC instruction is found
148	The CEM, DEM, or EEM instruction has been translated. However, the translation needs to be validated. These instructions have many parameters that cannot be directly translated and require review.	Each time a CEM, DEM or EEM instruction is found
149	Modbus messaging is not supported in the Logix Designer application.	If MSG instruction is configured for Modbus
150	MSG instruction and associated MESSAGE tag need to be manually verified.	Each time a MSG instruction is found
151	WARNING : Status files do not exist in the Logix Designer application. However this status file value is handled through the StatusFile routine.	S file type indexes that can be directly translated to functionality in the Logix Designer application
152	the Logix Designer application has a different fault handling mechanism than the PLC-5/SLC. This fault routine will not be called.	Start of identified legacy processor fault routine
153	This PII/DII routine is not used by the Logix Designer application.	Start of identified legacy processor PII/DII routine

I/O Modules

Supported I/O Modules

The majority of 1746 and 1747 discrete, analog, and specialty modules are compatible with the 1747-AENTR adapter.

<u>Table 3</u> provides a list of supported modules.

Table 2 1/0 Medules	Cupported by the	1747 AENTD	Adaptor
Table 3 - I/O Modules	Supported by the	2 1/4/-AENIK	Adapter

Catalog Number	Туре	Catalog Number	Туре
1746-IA4	AC Digital Input Module	1746-0G16	DC Digital Output Module
1746-IA8	AC Digital Input Module	1746-0V8	DC Digital Output Module
1746-IA16	AC Digital Input Module	1746-0V16	DC Digital Output Module
1746-IB8	DC Digital Input Module	1746-0V32	DC Output Module
1746-IB16	DC Digital Input Module	1746-0VP16	DC Digital Output Module
1746-IB32	DC Input Module	1746-0W4	AC/DC Relay Output Module
1746-IC16	DC Digital Input Module	1746-0W8	AC/DC Relay Output Module
1746-IG16	DC Digital Input Module	1746-0W16	AC/DC Relay Output Module
1746-IH16	DC Digital Input Module	1746-0X8	AC/DC Relay Output Module
1746-IM4	AC Digital Input Module	1746-FI04I	Analog Combination Module
1746-IM8	AC Digital Input Module	1746-FI04V	Analog Combination Module
1746-IM16	AC Digital Input Module	1746-INT4	Thermocouple Isolated Input Module
1746-IN16	AC/DC Digital Input Module	1746-NI4	Analog Input Module
1746-104	Digital Combination Module	1746-NI8 ⁽¹⁾	Analog Input Module
1746-108	Digital Combination Module	1746-NIO4I	Analog Combination Module
1746-1012	Digital Combination Module	1746-NIO4V	Analog Combination Module
1746-I012DC	Digital Combination Module	1746-N04I	Analog Output Module
1746-ITB16	DC Digital Input Module	1746-NO4V	Analog Output Module
1746-ITV16	DC Digital Input Module	1746-NR4	RTD/Resistance Input Module
1746-IV8	DC Digital Input Module	1746-NT4	Thermocouple/mV Input Module
1746-IV16	DC Digital Input Module	1746-NI16V ⁽¹⁾	Analog Input Module
1746-IV32	DC Digital Input Module	1746-NI16I ⁽¹⁾	Analog Input Module
1746-0A8	AC Digital Output Module	1746-NR8 ⁽¹⁾	RTD/Resistance Input Module
1746-0A16	AC Digital Output Module	1746-NT8	Thermocouple/mV Input Module
1746-0AP12	AC Digital Output Module	1746-N08I ⁽¹⁾	Analog Output Module
1746-0B6EI	DC Digital Output Module	1746-N08V ⁽¹⁾	Analog Output Module
1746-0B8	DC Digital Output Module	1746-HSTP1	Stepper Controller Module

Catalog Number	Туре	Catalog Number	Туре
1746-0B16	DC Digital Output Module	1746-HSCE ⁽²⁾	High-Speed Counter Module
1746-0B16E	DC Digital Output Module	1746-HSCE2 ⁽¹⁾	Multi-Channel High-Speed Counter Module
1746-0B32	DC Digital Output Module	1746-QS ⁽²⁾	Synchronized Axes Control Module
1746-0B32E	DC Digital Output Module	1746-OBP16	DC Digital Output Module
1746-0BP8	DC Digital Output Module	1746-BAS/B ⁽¹⁾⁽²⁾	BASIC Module
		1746-BAS-T ⁽¹⁾⁽²⁾	BASIC Module

Table 3 - I/O Modules Supported by the 1747-AENTR Adapter

(1) This module supports multiple operating classes. The 1747-AENTR adapter automatically promotes multiclass modules to the highest supported class. The 1746-NI16I, 1746-NI16V, 1746-NR8, 1746-NI8, 1746-N08I, 1746-N08V modules are promoted from class 1 to class 3. The 1746-BAS/B, 1746-BAS-T, and 1746-HSCE2 modules are promoted from class 1 to class 4.

(2) This specialty module uses Advanced module connection. Refer to the user manual specific to the I/O module to learn about its connection configuration requirements.

Unsupported I/O Modules

Table 4 lists unsupported modules. You can also have third-party SLC I/O modules in your system. Contact the third-party supplier to determine their product's compatibility. In general, third-party modules can be supported as long as the modules use fewer than 250 integer words and do not use G-files. However, a new EDS file needs to be developed to make the third-party module compatible with the 1747-AENTR adapter. If these modules are used in the current system, other plans must be made to incorporate the modules into a Logix system.

Consult the SLC EtherNet/IP Adapter Module user manual, publication <u>1747-UM076</u> for the latest list of supported and unsupported modules.

Catalog Number	Туре
1746-HSRV	Servo Control Module
1746-BTM ⁽¹⁾	Barrel Temperature Module
1747-DCM1 ⁽¹⁾	Direct Communication Modules
1747-DCM2 ⁽¹⁾	
1747-DCM3 ⁽¹⁾	
1747-DCM4 ⁽¹⁾	
1747-KE/A ⁽¹⁾	DH-485/RS-232C Interface Modules
1747-KE/B ⁽¹⁾	
1747-KFC15	ControlNet to RS-232C Interface Module
1747-SDN/D ⁽¹⁾	DeviceNet Scanner module
1747-SCNR ⁽¹⁾	ControlNet Scanner module
1747-SN	Remote I/O Scanner Module
1747-BSN	Back-Up Remote I/O Scanner Module
1746-QV	Open Loop Velocity Control Module
1746-BLM	Blow Molding Module
1746-MPM	Mold Pressure Module
1203-SM1 ⁽¹⁾	Scanport Module (Class 4 operation)

Table 4 - I/O Modules NOT Supported by the 1747-AENTR Adapter

 The module is not supported by the 1747-AENTR but appears in the the Logix Designer application pick list (Select Module Type dialog box).

IMPORTANTAny 1746/1747 module that is not included in the lists of supported and
unsupported modules is not supported by the 1747-AENTR, as of the
date of writing of this user manual.
Consult the manufacturer of any third-party module to determine if the
module is supported by the 1747-AENTR adapter.

Notes:

Performance Expectations

The data provided here was gathered by using real world testing and is provided as a guide to help you determine your expected results. The system consisted of a 1769-L36ERM module and a rack of 1746 I/O modules of different sizes and types. No two systems are alike and your system may be different than shown here. Use this data to help manage your performance expectations.

- Testing goal was to keep both the 1769-L36ERM % CPU and the 1747-AENTR % CPU under approximately 70%.
- Each user I/O module configuration is unique in terms of number and types of modules within the chassis. Test results vary based on exact chassis configuration.
- The data was gathered with all modules contained in a single 1746 chassis.
- RPIs of the various modules within the chassis do not need to be equal. You can adjust individual module RPIs to meet your application needs. The RPIs used in these tests were to extremely tax the system. Using RPIs of 2 and 4 mS is not considered typical.

Modules in chassis, tested to max size chassis 13 slots 1 - 1747-AENTR module 12 - I/O modules	1 - 1746-IB16 1 - 1746-0B16 (best case throughput)	1 - 1746-BAS 2 - 1746-NT4 2 - 1746-IB16 2 - 1746-0B16	1 - 1746-BAS 2 - 1746-NT4 5 - 1746-IB16 4 - 1746-0B16
All modules configured for same RPI	2 ms	2 ms	4 ms
Total number of INPUT bytes transferred across backplane	12	212	244
Total number of OUTPUT bytes transferred across backplane	4	184	192
L36ERM % Ethernet CPU, I/O Comms Utilization (Actual)	20%	71.5%	60.8%
1747-AENTR % CPU	23%	68%	66%
1747-AENTR backplane scan time Max/Avg	2 ms/2 ms	5 ms/5 ms	5 ms/5 ms
Typical discrete throughput with minimal Logix program scan (less than 1 ms)	711 ms	1119 ms	1219 ms
Typical discrete throughput with 15 ms Logix program scan	739 ms	1247 ms	1250 ms
Typical discrete throughput with 30 ms Logix program scan	970 ms	1276 ms	1185 ms

Table 5 - Performance - For Reference Only

While the Logix controller might not scan the I/O in the 1747-AENTR chassis as quickly as the SLC scans the I/O as local I/O, you may still see an overall performance improvement after the conversion to Logix because you are likely to see a significant program scan time decrease.

IMPORTANTLogix Designer application version 21 and later, and 1747-AENTR module
firmware revision 2.001 and later, support configurations of multiple physical
1746 chassis connected by cables and scanned by a single 1747-AENTR
module. Multi-chassis support lets you use up to 3 physical chassis, with a
maximum of 30 I/O slots, scanned by a single 1747-AENTR module.
The 1747-AENTR firmware revisions prior to revision 2.001 support only a
single physical chassis and 13 I/O slots maximum.

When the 1747-AENTR module is used in a multi-chassis system you can expect slower performance than the data presented in <u>Table 5</u>. The backplane scan time can increase by as much as 35% especially in systems with a large number of Input and Output bytes transferred across the backplane. The minimum RPI is also affected by the number of I/O modules within the chassis. For a 30-I/O-module chassis, the RPI must be at least 11 mS.

IMPORTANT Performance is affected by the Logix controller % CPU, 1747-AENTR % CPU, number of bytes In/Out transferred across the 1746 backplane, 1746 backplane scan time and Ethernet bandwidth. Your results may vary from the data in the table. The data in the table is meant for reference only.

Advanced Modules

Use Advanced Modules in a Logix System

The SLC 500 EtherNet/IP Adapter user manual, publication <u>1747-UM076</u>, has a section titled 'Add Specialty I/O Modules Using Advanced Connection' that covers using these modules. If your system has any of the advanced modules, you must review that section and plan accordingly.

Follow these steps to incorporate an advanced module in a Logix system.

1. On the General tab, configure the total size and type of data (SINT, INT, DINT, REAL) that exists in the SLC environment for your advanced module.

The values placed here determine the type and size of tag created in the Logix environment.

General Connection Con	General concepts about using an	
Type: 1746-BAS Vendor: Allen-Brad Parent: AENTR_1 Name: BAS_B	/B 1746-BAS/B ley 01	Advanced Module
Module Definition*		
Revision: 2 Electronic Keying: Con Connections:	npatible Module	
Name	Size	Input size includes 8 Input words and 64 M1 words for a total of 72.
Exclusive Owner - Advanced	Input: 72 Output: 72	Output size includes 8 Output
Exclusive Owner-Ad Used for 1746-HSCE and the 1746-BAS-T	words and 64 M0 words for a total of 72.	

2. On the Configuration tab, you are directing the Logix controller where and how to place the data from the Advanced module into the Logix tag.

Remember the advanced module is actually supplying Input data, Output data, M1 data and M0 data. This tab configures how to distribute the Advanced module data into the Logix tag.

	201022						
	ID A	Name		Value	Units	Style	Description
*	8	Chunk 1 Output Size	~	8		Decimal 👱	Chunk 1 Output Size=8, Is 8 Integers
	9	Chunk 1 Output File	~	Output File			equivalent to the SLC Output Image.
	10	Chunk 1 Output Offset	~	0		Decimal 😒	Chunk 2 Output Size=64, is 64 integers
	11	Chunk 2 Output Size	~	64	-	Decimal 💉	equivalent to the SIC MO file Both of
	12	Chunk 2 Output File	~	M0 File		2	those groups of integers are in a single
	13	Chunk 2 Output Offset	~	0		Decimal 💉	Le river a
h!	14	Chunk 3 Output Size	~	0		Decimal 💉	Logix tag.
	15	Chunk 3 Output File	~	M0 File		8	Chunk 1 Input Size-9 Is 9 Integers
	16	Chunk 3 Output Offset	~	0		Decimal 🔽	Cliulik Tiliput Size—o, is o liliegers
	17	Chunk 1 Input Size	~	8		Decimal 💉	equivalent to the SLC input image.
1	18	Chunk 1 Input File	~	Input File			Chunk 2 Input Size=64, is 64 integers
	19	Chunk 1 Input Offset	~	0		Decimal 💉	equivalent to the SLC M1 file. Both of
	20	Chunk 2 Input Size	~	64		Decimal 💉	these groups of integers are in a single
	21	Chunk 2 Input File	V	M1 File	1	10	Logix tag.

This Configuration dialog box maps Input data, Output data, MO, and M1 data from he SLC environment and places that data in single Logix Input and Output tag.

This is the Logix tag created with the Advanced module. The tag is a simple array (no descriptive tag names) of the size specified on the Module Definition dialog box from the Configuration tab. All of the data to/from the 1746 module show up in this tag based on the mapping specified on the Configuration tab.

- AENTR_101:1:1	{}		AB:1746_BASB_504289DA:1:0	
AENTR_101:1:I.ConnectionFaulted	0	Decimal	BOOL	
- AENTR_101:1:I.Data	{}	Decimal	INT[72]	A 72 Integer tag is created to hel
+ AENTR_101:1:I.Data[0]	0	Decimal	INT	data and M1 data. This tag is a si
+ AENTR_101:1:I.Data[1]	0	Decimal	INT	with no descriptive tags.
	0	Decimal	INT	
ÆNTR_101:1:I.Data[3]	0	Decimal	INT	

I	- AENTR_101:1:0	{}		AB:1746_BASB_7F28A5EE:0:0	Δ 72 In
	AENTR_101:1:0.Data	{}	Decimal	INT[72]	Output
	+ AENTR_101:1:0.Data[0]	0	Decimal	INT	simple
	+ AENTR_101:1:0.Data[1]	0	Decimal	INT	
	+ AENTR_101:1:0.Data[2]	0	Decimal	INT	
	+ AENTR_101:1:0.Data[3]	0	Decimal	INT	

ld the Input imple array

nteger tag is created to hold the data and MO data. This tag is a array with no descriptive tags.

Migrating MicroLogix 1500 controllers to CompactLogix

RSLogix Project Migrator tool

The RSLogix Project Migrator tool, version 3.0 or later, supports conversion of MicroLogix 1500 program to CompactLogix controllers.

In cases where the MicroLogix 1500 application does not use any 1769 Expansion I/O module, or uses 1769 I/O modules that have an equivalent 1762 I/O module replacement, we recommend migrating MicroLogix 1500 to MicroLogix 1400. MicroLogix 1500 users may also consider migrating to MicroLogix 1400 in applications that require use of serial ports connected to DH-485, DF1, ASCII or Modbus RTU networks. MicroLogix 1500 and MicroLogix 1400 use the same RSLogix 500/Micro programming software. MicroLogix 1500 programs can be converted to MicroLogix 1400 by changing the processor type in RSLogix 500/Micro.

Use the MicroLogix migration wizard in Integrated Architecture Builder for recommendation on what hardware bill of material to migrate to from MicroLogix 1500.

Figure 1 - MicroLogix Migration wizard in the Integrated Architecture Builder



To convert a MicroLogix 1500 program to a CompactLogix controller, refer to <u>Chapter 3</u> of this manual, since the process is similar.

If the I/O migration strategy is to retain the 1769 Expansion I/O modules as distributed I/O with 1769-AENTR, refer to <u>step 5</u> in <u>Chapter 3</u> to Keep existing I/O in a separate rack.

If the I/O migration strategy is to retain the 1769 Expansion I/O module as local I/O on CompactLogix L2Y controllers, refer to <u>step 5</u> in <u>Chapter 3</u> to Replace all I/O with equivalent newer models.

Numerics

1746-BAS/B 18 1746-BAS-T 18 1746-HSCE 18 1746-QS 18 1747-AENTR 8 1747-SDN 17 1747-SN 12 add I/O on-line 10 advanced modules 81 BTR 12 **BTW 12** connect through RJ45 69 connections 9 install 67 IP address 66 local I/O 11 power considerations 19 rack optimization 9 redundant system 10 remote I/O 12 supported I/O 75 supported rack size 14 unsupported I/O 76 1747-SDN 17

A

adapter 8 connections 9 add I/O on-line 10 additional resources 6 advanced modules 18, 81 ASCII file 45 asynchronous scans 13

В

backplane power considerations 19 power requirements 67 boot time 13 BootP/DHCP 66

C

chassis 68 code conversion 45 communication SLC to Logix 61 communication networks DH+ 18 DH485 18 Ethernet 18 serial 18 CompactLogix system 26 connection types exclusive owner 9 input only 9 listen only 9 none 9 conversion errors 52 converting messages 73 verifying 58

D

device-level ring 17 DeviceNet network 17 DH+ communication 18 DH485 communication 18 DHCP 66 DHCP enabled 66 download Integrated Architecture Builder 7

E

EDS files 14 errors syntax 52 Ethernet network 18 remote I/O connection 36 EtherNet/IP network connection 69 exclusive owner 9, 18

F

file conversion 45 file translation 43 future requirements 17 device-level ring 17 DeviceNet network 17

I/O asynchronous 13 issues with I/O modules 62 local rack 11 remote rack 12 retaining 14 scan time 11 synchronous 13 I/O tree 9, 14 I1 files 17 input only 9

Integrated Architecture Builder add a chassis 33 bill of material 41 download 7 location 7 network connection 36 replace with CompactLogix 26 retain I/0 20 integrated architecture builder 20 IP address 66

L

listen only 9 local I/O 11 Logix boot time 13 memory comparison 11 scan time 11 Logix Designer 5 Logix I/O I/O tree 9

М

M0 files 17, 18, 82 M1 files 17, 18, 82 map messages 61 memory comparison SLC to Logix 11 message instructions 59 migration add a chassis 33 future requirement 17 Integrated Architecture Builder 20 integrated architecture builder 20 replace with CompactLogix 26 retain I/0 20 migration planner 15 migration wizard 20 module discovery 10

Ν

network address 66 network connection 69 none 9

0

00 files 17 overview 7 SLC EtherNet/IP adapter module 8

Ρ

PCE locating instructions 58 message instructions 59 recognizing instructions 59 resolving 57, 59 timer instructions 59 PCE message list 73 PCE messages 73 performance 12 performance expectations 79 power considerations 19 power requirements 67 program conversion error locate 58 recognizing instructions 59 resolving 57, 59 project bill of material 41

R

rack optimization 9 redundant Logix system 10 remote I/0 12, 33 BTR 12 **BTW 12** network connection 36 scan time 12 replacing other components 71 requirements power 67 resolving program conversion error 59 resources 6, 7 retain I/O 14, 20 **RJ45** wire 69 **RPI** 11 **RS232 port** 19 **RSLogix 5000** 5 file translation tool 43

S

scan time comparison 11 scan times 79 serial communication 18 SLC memory comparison 11 replace with CompactLogix 26 scan time 11 SLC EtherNet/IP adapter module connections 9 overview 8 SLC I/O local rack size 14 remote rack size 14 Studio 5000 5 support add on-line 10 module discovery 10 supported I/O 75 supported rack size 14 switches network 66 synchronous scans 13 syntax errors 52

Т

TCP 67 timer issues 59 timer.ACC 59 timer.PRE 59 tools file translation 43 integrated architecture builder 7 migration planner 15 translate program 50 translation tool expectations 45 RSLogix 500 50 RSLogix 5000 50

U

unsupported I/O 76

V

verifying 58

Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products. At <u>http://www.rockwellautomation.com/support</u>, you can find technical manuals, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools. You can also visit our Knowledgebase at <u>http://www.rockwellautomation.com/knowledgebase</u> for FAQs, technical information, support chat and forums, software updates, and to sign up for product notification updates.

For an additional level of technical phone support for installation, configuration, and troubleshooting, we offer TechConnectSM support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <u>http://www.rockwellautomation.com/support/</u>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the <u>Worldwide Locator</u> at <u>http://www.rockwellautomation.com/support/americas/phone_en.html</u> , or contact your local Rockwell Automation representative.

New Product Satisfaction Return

Rockwell Automation tests all of its products to help ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication <u>RA-DU002</u>, available at <u>http://www.rockwellautomation.com/literature/</u>.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444 Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640 Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846